# zencontrol

# smartscape connected lighting systems



# Smart switch rotary datasheet



#### **Features**

- 2 mA DALI line current
- Up to 63 units per DALI line
- Black and white finishes available
- Tactile knobs for user accessibility
- Customisable LED colour to suit different applications
- Use on wired and wireless DALI networks



### Integrated illumination

Configurable colour LED indicator for feedback/status



### Inbuilt temperature sensor

Wall mount location for improved temperature accuracy



### Wireless interface

App configurable with direct connect to zencontrol mesh



### DALI-2 input

Designed for use with compliant DALI-2 application controllers

# zencontrol



## Smart switch rotary datasheet




### Product range

Order code	Description
zc-ss-rot-wht	Smart switch rotary to suit 84 mm wall mount, white
zc-ss-rot-blk	Smart switch rotary to suit 84 mm wall mount, black

#### **Features**

- 2 mA DALI line current
- Up to 63 units per DALI line
- Black and white finishes available
- Tactile knob for user accessibility
- Customisable LED colour to suit different applications
- Use on wired and wireless DALI networks

### Dimensions (mm)



#### **Notice**

- The DALI line is not SELV. It must be treated like LV mains and treated with the same precautions and wiring regulations.
- This product is not bus powered and requires the 240V supply to be connected.

### **Specifications**


220 - 240 V~ 50Hz 4mA
II
Wired DALI-2 Wireless IEC62386-104 over Thread
IEEE 802.15.4
2.4 GHz
+8 dBm
2 mA
0.5 - 2.5 mm <sup>2</sup> Strip 7 mm
0 to 55°C
PC UV stabilised, toughened glass, aluminium
IP20
IEC 61347-2-11 EMC-2004/108/EC CISPR 15 LVD-2006/95/EC IEC 62386-301 IEC 62386-104

### System overview: modes

**104 mode** is enabled after the device has been added to a 104 application controller such as zc-iot-fc.



 ${\bf 104+101}$  Bridge mode is enabled after the device has been added to a 104 controller and a 101 power supply has been connected to the DALI terminals.



**101 mode** is enabled after a 101 power supply has been connected to the DALI terminal and the device **has not** been added to a 104 application controller.

